

18

ECH762V
ECH762R
ECH762VM
ECH762
ECH762VTM
ECH762RTM
ECH762RM



19

ECH880
ECH116L
SC508EH
ECH880R
ECH116R
SC508EHM



20

Pluggable for Through-hole reflow

21

ECH350V(ECH381V)-...PTHT
ECH350R(ECH381R)-...PTHT
ECH350VM(ECH381VM)-...PTHT
ECH350RM(ECH381RM)-...PTHT



THT

22

5EHDV(2EHDV)-...PTHT
5EHDVC(2EHDVC)-PTHT
5EHDVM(2EHDVM)-...PTHT
ECHK1(Key code for ECH381
5EHDR(2EHDR)-...PTHT
5EHDRC(2EHDRC)-PTHT
5EHDRM(2EHDRM)PTHT
EHDK1(Key code for EHD series)



23

0134-40
0134-41
0134-11
0134-12
0134-13
0134-14
0134-21
0134-23

0134 / 0135




24

0134-31
0134-32
0134-33
0134-34



25

0135-40
0135-41
0135-10
0135-11
0135-14
0135-15
0135-16
0135-17



26

0135-18
0135-19
0135-12
0135-13
0135-20
0135-21
0135-24
0135-25



27

0135-30
0135-31
0135-34
0135-35
0135-36
0135-37
0135-38
0135-39



28

SC508WH
0135L1
0135L2



29

0134 & 0135 Pluggable type cross reference list



30

PCB Terminal Blocks

European P.C.B. type terminal blocks

31

EK254V
EK350A
EK350V
EK350V4L
EK381A
EK381V
EEK381V
EK381V4L

EK/ESK



32

EK381V4R
ELK500A(ELK508A)
EELK508V-...P / EELK508V-...P
EK381V3L
ELK508V-...P / ELK508V-...P



33

EK500A(EK508A)
EK500V(EK508V)
EEK500V(EK508V)
EK500V2L(EK508V2L)
E3K500V(E3K508V)
EK500V4L(EK508V4L)
EK500V4R(EK508V4R)
EK500V2R(EK508V2R)



34

EK500V3L(EK508V3L)
EK500R(EK508R)
EK500BD
EK500BD-...P5



35

EHK381V
EHK500V(EHK508V)
EEHK508V
EHK508V2L
EHK508V3L
EHK500R(EHK508R)
EHK750V(EHK762V)

